

OpenSUSE 11.2 (Intel 945GSE)

X.Org X Server 1.6.5

Kernel: 2.6.31.5-0.1-desktop

Install History

1. Using Failsafe mode to login
2. <Ctrl>+<Alt>+<Backspace> and select console mode to close X window
3. cp /etc/X11/xorg.conf.install /etc/X11/xorg.conf or use “X –configuration” to create xorg.conf file.
4. Test the xorg.conf setting, “X –configure /etc/X11/xorg.conf”
5. reboot
6. #YaST2 –i gcc
7. #YaST2 –i make
8. install realtek-linux-audiopack-4.07b.tar.bz2 driver
9. install Idealtek touch driver (RS232)

Trouble Shooting

1. Use the “setserial –g /dev/ttyS?” command to list the serial ports. That should be 6 serial ports on the system.
2. If the serial ports is not correctly, you can add the “8250.nr_uarts=6” on the kernel line (/boot/grub/menu.lst).
3. Use the “od –h –w10 </dev/ttySX” to check the device is working. (X means the serial port number, COM5=ttyS4, X=4)

xorg.conf

Section "Device"

Identifier "vesa"

Driver "vesa"

EndSection

Section "Screen"

Identifier "vesa"

Device "vesa"

EndSection

Section "ServerLayout"

Identifier "Layout"

#Screen "vboxvideo"

#Screen "vmware"

#Screen "cirrus"

#Screen "fbdev"

Screen "vesa"

InputDevice "Touchscreen0" "SendCoreEvents"

EndSection

Section "InputDevice"

Identifier "Touchscreen0"

Driver "xfdrvtouch"

Option "Device" "/dev/ttys4"

Option "ScreenNo" "0"

Option "Rotation" "0"

Option "SwapY" "0"

Option "DebugLevel" "0"

Option "UpSound" "1"

Option "DownSound" "1"

Option "RightButtonON" "1"

EndSection