How to enable and install USB 3.0 driver in Windows 7 on Baytrail M/D/I platform:

Step1: XHCI mode [Disable] and EHCI Controller [Enable] then install Windows 7.

	Phoenix SecureCore Technology				
Advanced					
USB Configuration					
xHCI Mode [<mark>Disable</mark>] EHCI Controller [Enable]					

Step2: After installation Windows 7 is done, select BIOS XHCI mode to [Smart Auto].

		Phoenix SecureCore Technology Setup				
Advanc	ed					
USB Configuration						
xHCI Mode	<mark>I</mark> Smart Autol					
EHCI Controller	[Enable]					

Step3-1: Install USB 3.0 driver in windows 7.

- Mice and other pointing devices
 Monitors
 Network adapters
 Other devices
 Universal Serial Bus (USB) Controller
 Portable Devices
- Ports (COM & LPT)





Step4: When install USB 3.0 driver is done, adjust BIOS XHCI mode [Enable] and EHCI Controller [Disable].

		Phoenix	SecureCore	Technology	Set
Advance	d				
		USB Configuration			
xHCI Mode EHCI Controller	[<mark>Enable</mark>] [Disable]				

Follow above steps now your USB 3.0 work well in Windows 7.